

Portable Smart Motion Sensor

BY
JASCO®



Model 34193 / ZW6302

KEY FEATURES

- Remote Monitoring
 - Monitor area from a distance with smartphones or tablets
- Trigger Automations
 - Activate scenes or lights when motion is detected
- Sends Alerts
 - Be notified when activity is detected
- Dual power options
 - Runs for up to 2 years using CR123A batteries (included) or use the Micro USB port (cable not included)
- OTA (Over-the-Air) Updateable
 - Utilizes the Z-Wave Firmware Update Meta Data command class for standardized wireless firmware updates

SPECIFICATIONS

Power 2 x CR123A Batteries or Micro USB

Signal (Frequency) 908.4/916 MHz

Range: Up to 150 feet line of sight between the wireless controller or the closest Z-Wave device

Operating Temperature: 32-104° F (0-40° C)

For Indoor Use Only

REGULATORY CERTIFICATIONS



Portable Smart Motion Sensor

BY
JASCO®



Model 34193 / ZW6302

Z-WAVE MANUFACTURER SPECIFIC INFORMATION

<http://products.z-wavealliance.org/products/1902>

Z-Wave Certification Number: ZC10-16085167

Manufacturer ID: 0x0063

Product Type ID: 0x4953

Product ID: 0x3133

SUPPORTED COMMAND CLASSES

Supported Command Classes

- Association Group Information V1
- Association V2
- Battery V1
- Configuration V1
- Device Reset Local V1
- Firmware Update MD V2
- Manufacturer Specific V2
- Notification V4
- Powerlevel V1
- Sensor Binary V2
- Version V2
- Wake-Up V2
- Z-Wave Plus Info V2

Controlled Command Classes

- Basic V1

MANUAL BUTTON PRESS FEATURES

Functions	Button Press Method
Test Mode	Press and hold button for 10 seconds
Adjust Motion Sensitivity	Press and hold button for 3 seconds

Portable Smart Motion Sensor

BY JASCO®



Model 34193 / ZW6302

ADJUSTABLE CONFIGURATIONS

PARAMETER			
Number	Size	Name	Values
13	1	PIR Sensitivity Setting	1 - Low 2 - Medium 3 (Default) - High
18	1	PIR Timeout Duration	1 to 60 (Default) - 1 min to 60 mins
20	1	Basic Set, Notification and Basic Report	1 (Default) - Motion Sensor will send out
28	1	Enable/Disable the LED indication when PIR is triggered	0 - Disable 1 (Default) - Enable

FACTORY RESET

Press the button 10 times within 6 seconds (interval between presses cannot be longer than 1 second)
Blue LED will blink for 3 seconds to signal a successful reset